

MULTI-SURFACE
CERAMIC
CLEARCOAT
PURE AIR COATING

You will need:

Mop/mop bucket
Laundered flat looped microfiber mop
Red and green pads
2 gallon pump-up sprayer
SIMIX Multi-Surface Cleaner/Degreaser/Sanitizer
SIMIX Multi-Surface Ceramic Clearcoat
Distilled or RO water

Clean, Restore and Coat LVT and LVP Flooring

INSTRUCTIONS

It is imperative that the floor is completely stripped.

Step 1: If any coating is present strip floor of all dirt, grime and or old coatings.

Step 2: Now rinse floor well with 1 small scoop of **SIMIX Multi-Surface Cleaner/Degreaser/Sanitizer** to 1 gallon of warm water. Let floor dry.

Apply SIMIX Multi-Surface Ceramic Clearcoat

Step 1: Mix **SIMIX Multi-Surface Ceramic Clearcoat** 4 parts water with 1 part coating in pump-up sprayer. (use distilled or RO water)

Step 2: Apply coating and spread using a laundered flat looped microfiber mop. Apply thin coats. Do not allow coating to puddle. Each coat will take 5 to 10 minutes to dry.

Step 3: Apply 4 coats. After 4th coat is dry wait 30 minutes before replacing all the items back on the floor. Can add 4-6 total coats for added protection.

SIMIX®